



Spray nozzles

CLEANING AND SENT OUT FROM THE SPRAY
NOZZLES
JUNI 2020-V1-EN

Berg Hortimotive
Burg. Crezeelaan 42a
2678 KZ De Lier
The Netherlands

Phone +31 (0)174-517 700
info@berghortimotive.com
berghortimotive.com

Service
Phone +31 (0)174-613 293
service@berghortimotive.com

SPRAY NOZZLES



Avoid clogging:
 Clean after each spray activity the pipes, filters and nozzles with clean water. The flow and flushing prevents residues accumulate resources. Without rinsing there is a risk of clogging in the cap and precipitate on the outside of the nozzle. This can cause an abnormal spray pattern.

Check before spraying the nozzles with clean water for obstructions.

Maximum pressure on the spray boom is 15 bar!

Spray nozzle table TeeJet		
	Pressure	Send out Ltr / min
8001 orange	4	0.46
	5	0.51
	6	0.56
	7	0.60
	10	0.72
	20	1.00
80015 green	4	0.68
	5	0.75
	6	0.82
	7	0.88
	8	0.94
	9	1.00
	10	1.04
	11	1.10
	12	1.15
	13	1.19
	14	1.23
8002 yellow	4	0.90
	5	1.01
	6	1.10
	7	1.18
	8	1.26
	9	1.33
	10	1.40
	11	1.47
	12	1.53
	13	1.59
	14	1.65
8003 blue	4	1.37
	5	1.52
	6	1.67
	7	1.80
	8	1.93
	9	2.04
	10	2.15
	11	2.25
	12	2.35
	13	2.45
	14	2.54
15	2.63	
16	2.72	